

ADAPTIVATION

I N C O R P O R A T E D

Tek Pal UTR

(Switch Input)

The Tek Pal Universal TV Remote has four switch inputs (ON/OFF, VOL +, VOL - and CH +). Almost any standard switch (1/8" plug) can be used (not compatible with Taction Pads).

To Program:

1. Manually turn on TV.
2. Press and hold ON/OFF and MUTE buttons together for 3 seconds.
3. The indicator light will remain on.
4. Press and release CH+ (or CH-) button until TV shuts off (may take several minutes of pressing before code is found).
5. Press MUTE button immediately after TV shuts off to complete set-up.
6. The indicator light will blink 3 times indicating you've successfully programmed your Tek Pal UTR.

Switch Inputs:

To operate desired function (ON/OFF, VOL +, VOL - and CH +), simply plug switch into the corresponding jack.

2225 W. 50th St., Ste 100
Sioux Falls, SD 57105
www.adaptivation.com
(800) 723-2783